

ASSEMBLY INSTRUCTIONS FOR MERIDIAN M10 ACTIVE LOUDSPEAKERS

1. PARTS SUPPLIED

- 2 x ACOUSTIC ENCLOSURES PACKED ONE PER CARTON.
- 2 x AMPLIFIER/STANDS PACKED TWO PER CARTON WITH LEAD SET.
- 2 x GRILLE BOXES PACKED TWO PER CARTON.
- 1 x FITTING KIT PACKED WITH AMPLIFIER/STANDS COMPRISING:
 - 2 x WIRE POWER PLUG RETAINING CLIPS.
 - 4 x 2BA x 2 1/2 INCH HEX HEAD BOLTS.
 - 4 x 2BA x 1 INCH WASHERS.
 - 1 x ALLEN WRENCH (SLIM).
 - 2 x 2.5 AF. QUICK BLO FUSES.
 - 2 x 3.15 AT SLO BLO FUSES.
 - 2 x 3.15 AF QUICK BLO FUSES.

2. ASSEMBLY INSTRUCTIONS

- A. REMOVE BOTH ACOUSTIC ENCLOSURES FROM ALL PACKAGING AND STAND HEAD TO THE FLOOR WITH A PROTECTIVE CARD BENEATH. SCREW IN 2 x 2 BA BOLTS WITH 1" x 2BA WASHERS INTO HOLES PROVIDED, LEAVING APPROX. 1/8" GAP BETWEEN UNDERSIDE OF WASHERS.
- B. REMOVE BOTH AMPLIFIER/ STANDS FROM PACKAGING AND POSITION ONE UPTURNED UNIT SUCH THAT BOLTS ARE LOCATED IN THE RECESSES PROVIDED. TIGHTEN THE UNITS TOGETHER HARD WITH THE ALLEN WRENCH PROVIDED.
- C. PLUG IN CABINET CONNECTORS HAVING LOCATED AND ALIGNED THE KEYWAYS. TURN THE ASSEMBLY RIGHT SIDE UP.
- D. FIT MERIDIAN SIGNAL LEADS PROVIDED: IT IS ACOUSTICALLY PREFERABLE TO PLUG LOUDSPEAKERS DIRECT INTO A WALL SOCKET RATHER THAN SWITCH FROM THE OUTLET ON THE 101. A POWER ON OFF SWITCH IS LOCATED ON THE REAR INSIDE PANEL AT THE LEFT HAND SIDE.
- E. REMOVE 2 MERIDIAN FOOT BARS FROM FRONT OF SPEAKERS USED FOR PROTECTION.